

The Tamarack “Perfect Balance” In-Door Air Pressure Relief System



STEP 1

Layout Template



STEP 2

Cut Door



STEP 3

Attach Perfect Balance



STEP 4

Secure Perfect Balance with two screws

PRESSURE BALANCED!

To see an installation video, visit www.tamtech.com!